



10/550445

図 1




10/550445

図 2




10/550445

3




10/550445

図 4



10/550445


図 5



- | | | | |
|----|-----------|----|----------------------------------|
| 12 | ワンブッシュボタン | 12 | WIRELESS COMMUNICATION CIRCUIT |
| 23 | 開閉検知スイッチ | 23 | OPENING/CLOSING DETECTION SWITCH |
| 21 | 回路制御部 | 21 | CIRCUIT CONTROL SECTION |
| 24 | 受話器 | 24 | TELEPHONE RECEIVER |
| 25 | 送話器 | 25 | TELEPHONE MICROPHONE |
| 5 | キー操作部 | 5 | KEY OPERATION SECTION |
| 5a | 通話キー | 5a | TALK KEY |
| | ダイヤルキー | | DIAL KEY |
| | 通話終了キー | | TALK COMPLETION KEY |
| | その他の操作キー | | OTHER OPERATION KEYS |

10/550445

図 6



11 INCOMING CALL
 12 HOUSING OPENING/CLOSING DETECTION
 13 OPENING
 14 CLOSING
 15 TALK KEY LED OFF
 16 ONE-PUSH BUTTON LED ON
 17 HOUSING OPENING/CLOSING DETECTION
 18 OPENING
 19 CLOSING
 20 ONE-PUSH BUTTON LED OFF
 21 TALK OVER PHONE
 22 TALK KEY LED ON
 23 ONE-PUSH BUTTON LED OFF
 24 HOUSING OPENING/CLOSING DETECTION
 25 OPENING
 26 CLOSING
 27 TALK KEY
 28 TALK KEY LED OFF

10/550445

図 7

着信時のLED状態

	開	閉	閉 → 開
ワンプッシュボタン LED	OFF	ON	OFF
通話キー LED	ON	OFF	OFF
着信 LED	ON	ON	OFF

着信時のLED状態

ワンプッシュボタンLED

通話キーLED

着信LED

開

閉

閉 → 開

LED STATE AT THE TIME OF INCOMING CALL

ONE-PUSH BUTTON LED


TALK KEY LED

INCOMING CALL LED

OPENING

CLOSING

CLOSING → OPENING



S22 HOUSING OPENING/CLOSING DETECTION
開 OPENING
閉 CLOSING
S23 ONE-PUSH BUTTON LED OFF
S24 TALK KEY LED ON
S25 CAR-MOUNTED ADAPTER CONNECTED
(EXTERNAL IF INSERTED)
有 YES
無 NO
S26 HANDS-FREE SWITCH OF CAR-MOUNTED AD
S29 EARPHONE INSERTED
有 YES
無 NO
S30 EARPHONE SWITCH
S31 TALK KEY
S27 TALK KEY LED OFF
S28 TALK OVER PHONE
S32 ONE-PUSH BUTTON LED ON
S33 TALK KEY LED OFF
S34 CAR-MOUNTED ADAPTER CONNECTED
(EXTERNAL IF INSERTED)
有 YES
無 NO
S35 HANDS-FREE SWITCH OF CAR-MOUNTED AD
S37 EARPHONE INSERTED
有 YES
無 NO
S38 EARPHONE SWITCH
S39 HOUSING OPENING/CLOSING DETECTION
開 OPENING
閉 CLOSING
S36 ONE-PUSH BUTTON LED OFF